

Instructions for your compost toilet!

- * Place the toilet on a base of newspaper, cardboard or similar. The tub is **only designed** as a latrine, and not for dishwater, rubbish, sanitary pads or other items.
 - * Before use, strew a thin layer (about 2 cm) of our TOA Skogsströ sawdust to cover the bottom of the tub.
 - * Add a small amount (1 dl) of TOA Skogsströ. Sawdust at regular intervals so the compost in the toilet maintains a porous structure and correct moistness. If the mass becomes too fluid, add a little more TOA Skogsströ. Should the mass become dry, it may start to smell. In such case, add a little water.
 - * **When the toilet is full** (max 15 kg), remove the seat and put on the accompanying lid. Take a new tub, assemble the seat and strew a thin layer of TOA Skogsströ. Sawdust to cover the bottom of the tub.
 - * The full tub must be placed in the **hallway** to be changed together with all related materials so we can assess your requirements. **Tubs should never be placed in the staircase**, with consideration to your neighbours and the risk of fire.
- * Tubs are changed once a week as required or as instructed.**

The appliance is particularly useful when undertaking major plumbing work or bathroom refurbishments or similar projects. Skogstoan AB is environmentally certified as per ISO 14001 and quality certified as per ISO 9001.

Skogstoan AB
Krossgatan 29
162 50 VÄLLINGBY

Tel: +46 (0)8-37 92 48
www.skogstoan.se
info@skogstoan.se